



# Firmware Update PIEGA Wireless


1. Lade die aktuelle Software (.bin) auf einen USB Memory Stick. Achte darauf, dass es jeweils eine Software Version für den Lautsprecher und eine weitere für das PIEGA connect gibt.  
Bemerkung: Verwende eine FAT32 oder FAT16 Formatierung.
2. USB Memory Stick beim Service Anschluss einstecken.  
Bemerkung: Lautsprecher oder PIEGA connect noch nicht mit Strom versorgen.



3. Versorge Lautsprecher oder PIEGA connect mit Strom.




4. Die Gruppen-Status Anzeige blinkt in der Farbe Magenta.




5. Das Update war erfolgreich, wenn die Status Anzeige entweder weiss, blau oder rot leuchtet.
6. Entferne den USB Memory Stick.

# Firmware update PIEGA Wireless


1. Download software update from webpage and store on USB flash drive (USB Memory stick). Please consider that there is one software version for the loudspeaker and another for the PIEGA connect. Note: Use FAT32 or FAT16 format.
2. Plug flash drive into USB service port of Speaker or PIEGA connect, Note: Speaker or PIEGA connect not powered yet



3. Power Speaker or PIEGA connect



4. Group Indicator is flashing in magenta colour



5. Update complete, when indicator LED changes over to white, blue or red
6. Remove USB flash drive