




Firmware update PIEGA Wireless


1. Download software update from webpage and store on USB flash drive (USB Memory stick). Please consider that there is one software version for the loudspeaker and another for the PIEGA connect. Note: Use FAT32 or FAT16 format.
2. Plug flash drive into USB service port of Speaker or PIEGA connect.
Note: Speaker or PIEGA connect not powered yet



3. Power Speaker or PIEGA connect



4. Group Indicator is flashing in magenta colour



5. Update complete, when indicator LED changes over to white, blue or red
6. Remove USB flash drive